



OM-246 011C

2011-09

**Processes**



Submerged (SAW) Welding


**Description**



Arc Welding Power Source

# Subarc AC/DC 1000/1250

## CE



# OWNER'S MANUAL



Visit our website at

[www.MillerWelds.com](http://www.MillerWelds.com)

File: Submerged (SAW)



# From Miller to You

---

*Thank you and congratulations* on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite.

We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide the exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.



Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual specification sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at [www.MillerWelds.com](http://www.MillerWelds.com) on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.





# DECLARATION OF CONFORMITY

for European Community (CE marked) products.

**MILLER Electric Mfg. Co., 1635 Spencer Street, Appleton, WI 54914 U.S.A. declares that the product(s) identified in this declaration conform to the essential requirements and provisions of the stated Council Directive(s) and Standard(s).**

Product/Apparatus Identification:

Product	Stock Number
Subarc AC/DC 1000	907454
Subarc AC/DC 1250	907456

Council Directives:

- 2006/95/EC Low Voltage
- 2004/108/EC Electromagnetic Compatibility

Standards:

- IEC 60974-1:2005 Arc welding equipment – Part 1: Welding power sources
- IEC 60974-10:2007 Arc Welding Equipment – Part 10: Electromagnetic compatibility (EMC) requirements
- EN 50445:2008 Product family standard to demonstrate compliance of equipment for resistance welding, arc welding and allied processes with the basic restrictions related to human exposure to electromagnetic fields (0 Hz – 300Hz)

Signatory:

July 19, 2011

---

**David A. Werba**

MANAGER, PRODUCT DESIGN COMPLIANCE

---

Date of Declaration

# TABLE OF CONTENTS

<b>SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING</b> .....	<b>1</b>
1-1. Symbol Usage .....	1
1-2. Arc Welding Hazards .....	1
1-3. Additional Symbols For Installation, Operation, And Maintenance .....	3
1-4. California Proposition 65 Warnings .....	4
1-5. Principal Safety Standards .....	4
1-6. EMF Information .....	4
<b>SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION</b> .....	<b>5</b>
2-1. Symboles utilisés .....	5
2-2. Dangers relatifs au soudage à l'arc .....	5
2-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance .....	7
2-4. Proposition californienne 65 Avertissements .....	8
2-5. Principales normes de sécurité .....	9
2-6. Informations relatives aux CEM .....	9
<b>SECTION 3 – DEFINITIONS</b> .....	<b>11</b>
3-1. Warning Label Definitions .....	11
3-2. Symbol Definitions .....	12
3-3. WEEE Label (For Products Sold Within The EU) .....	12
<b>SECTION 4 – INSTALLATION</b> .....	<b>13</b>
4-1. Important Information Regarding CE Products (Sold Within The EU) .....	13
4-2. Serial Number And Rating Label Location .....	13
4-3. Specifications .....	13
4-4. Duty Cycle and Overheating .....	14
4-5. Dimensions And Weight .....	14
4-6. Selecting a Location .....	15
4-7. Weld Output Terminals And Selecting Cable Sizes* .....	16
4-8. Connecting Weld Output Cables .....	17
4-9. Terminal Strip TE1, TE2 and Remote 14 Receptacle RC7 Information .....	18
4-10. Basic Sub Arc (SAW) Welding .....	19
4-11. 115 Volts AC Receptacle And Circuit Breaker 460 Volt Models .....	22
4-12. 230 Volts AC Receptacle And Circuit Breakers (400 Volt Input Models) .....	22
4-13. Electrical Service Guide .....	23
4-14. Connecting Input Power .....	25
4-15. Matching Primary Lines L1, L2, And L3 When Using Multiple AC Units .....	26
<b>SECTION 5 – MAKING WELD OUTPUT CONNECTIONS</b> .....	<b>27</b>
5-1. Work And Electrode Cable Connections For Single DC or AC Arcs .....	27
5-2. Connecting Multiple Units .....	28
5-3. Using AC Arcs Terminal Strip TE1 Connections .....	29
<b>SECTION 6 – OPERATION</b> .....	<b>30</b>
6-1. Front Panel Controls For Non-CE Models .....	30
6-2. Front Panel Controls For CE Models .....	31
<b>SECTION 7 – MAINTENANCE AND TROUBLESHOOTING</b> .....	<b>32</b>
7-1. Routine Maintenance .....	32
7-2. Fuse F1 .....	32
7-3. Access Area Supplementary Protectors .....	33
7-4. Troubleshooting .....	33
<b>SECTION 8 – ELECTRICAL DIAGRAMS</b> .....	<b>34</b>
<b>SECTION 9 – PARTS LIST</b> .....	<b>38</b>
<b>OPTIONS AND ACCESSORIES</b>	
<b>WARRANTY</b>	

# SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som 2011-01

 Protect yourself and others from injury — read and follow these precautions.

## 1-1. Symbol Usage



**DANGER!** – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

**NOTICE** – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

## 1-2. Arc Welding Hazards



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.



Only qualified persons should install, operate, maintain, and repair this unit.



During operation, keep everybody, especially children, away.



### ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.

- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

### SIGNIFICANT DC VOLTAGE exists in inverter welding power sources AFTER removal of input power.

- Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



### HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



### FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



### ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.




### WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.
- Do not use welder to thaw frozen pipes.

- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.



### FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.




### BUILDUP OF GAS can injure or kill.

- Shut off compressed gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



### ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.


- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



### NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



### CYLINDERS can explode if damaged.

Compressed gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

## 1-3. Additional Symbols For Installation, Operation, And Maintenance




### FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




### FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.




### OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



### FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.



### STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



### MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.




### WELDING WIRE can injure.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




### MOVING PARTS can injure.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.




### READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



### H.F. RADIATION can cause interference.




- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.




### ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.


## 1-4. California Proposition 65 Warnings

-  **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**
-  **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. *Wash hands after handling.***
-  **This product contains chemicals, including lead, known to the state of California to cause cancer, birth defects, or other reproductive harm. *Wash hands after use.***

### For Gasoline Engines:

-  **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

### For Diesel Engines:

-  **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

## 1-5. Principal Safety Standards

*Safety in Welding, Cutting, and Allied Processes*, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: [www.global.ihs.com](http://www.global.ihs.com)).

*Safe Practices for the Preparation of Containers and Piping for Welding and Cutting*, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: [www.global.ihs.com](http://www.global.ihs.com)).

*National Electrical Code*, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: [www.nfpa.org](http://www.nfpa.org) and [www.sparky.org](http://www.sparky.org)).

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1, from Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (phone: 703-788-2700, website: [www.cganet.com](http://www.cganet.com)).

*Safety in Welding, Cutting, and Allied Processes*, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: [www.csa-international.org](http://www.csa-international.org)).

*Safe Practice For Occupational And Educational Eye And Face Protection*, ANSI Standard Z87.1, from American National Standards Institute,

25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: [www.ansi.org](http://www.ansi.org)).

*Standard for Fire Prevention During Welding, Cutting, and Other Hot Work*, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: [www.nfpa.org](http://www.nfpa.org)).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: [www.osha.gov](http://www.osha.gov)).

U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (phone: 301-504-7923, website: [www.cpsc.gov](http://www.cpsc.gov)).

*Applications Manual for the Revised NIOSH Lifting Equation*, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: [www.cdc.gov/NIOSH](http://www.cdc.gov/NIOSH)).

## 1-6. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). Welding current creates an EMF field around the welding circuit and welding equipment. EMF fields may interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, access restrictions for passers-by or individual risk assessment for welders. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Do not place your body between welding cables. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.

4. Keep head and trunk as far away from the equipment in the welding circuit as possible.
5. Connect work clamp to workpiece as close to the weld as possible.
6. Do not work next to, sit or lean on the welding power source.
7. Do not weld whilst carrying the welding power source or wire feeder.

### About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.



# SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

fre\_som\_2011-01

**!** Se protéger et protéger les autres contre le risque de blessure — lire et respecter ces consignes.

## 2-1. Symboles utilisés



**DANGER!** – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.



Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

**NOTE** – Indique des déclarations pas en relation avec des blessures personnelles.

 Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Consulter les symboles et les instructions ci-dessous y afférant pour les actions nécessaires afin d'éviter le danger.

## 2-2. Dangers relatifs au soudage à l'arc



Les symboles représentés ci-dessous sont utilisés dans ce manuel pour attirer l'attention et identifier les dangers possibles. En présence de l'un de ces symboles, prendre garde et suivre les instructions afférentes pour éviter tout risque. Les instructions en matière de sécurité indiquées ci-dessous ne constituent qu'un sommaire des instructions de sécurité plus complètes fournies dans les normes de sécurité énumérées dans la Section 2-5. Lire et observer toutes les normes de sécurité.



Seul un personnel qualifié est autorisé à installer, faire fonctionner, entretenir et réparer cet appareil.



Pendant le fonctionnement, maintenir à distance toutes les personnes, notamment les enfants de l'appareil.



### UNE DÉCHARGE ÉLECTRIQUE peut entraîner la mort.

Le contact d'organes électriques sous tension peut provoquer des accidents mortels ou des brûlures graves. Le circuit de l'électrode et de la pièce est sous tension lorsque le courant est délivré à la sortie. Le circuit d'alimentation et les circuits internes de la machine sont également sous tension lorsque l'alimentation est sur Marche. Dans le mode de soudage avec du fil, le fil, le dérouleur, le bloc de commande du rouleau et toutes les parties métalliques en contact avec le fil sont sous tension électrique. Un équipement installé ou mis à la terre de manière incorrecte ou impropre constitue un danger.

- Ne pas toucher aux pièces électriques sous tension.
  - Porter des gants isolants et des vêtements de protection secs et sans trous.
  - S'isoler de la pièce à couper et du sol en utilisant des housses ou des tapis assez grands afin d'éviter tout contact physique avec la pièce à couper ou le sol.
  - Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
  - Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
  - Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
  - D'autres consignes de sécurité sont nécessaires dans les conditions suivantes : risques électriques dans un environnement humide ou si l'on porte des vêtements mouillés ; sur des structures métalliques telles que sols, grilles ou échafaudages ; en position coincée comme assise, à genoux ou couchée ; ou s'il y a un risque élevé de contact inévitable ou accidentel avec la pièce à souder ou le sol. Dans ces conditions, utiliser les équipements suivants,
- dans l'ordre indiqué : 1) un poste à souder DC à tension constante (à fil), 2) un poste à souder DC manuel (électrode) ou 3) un poste à souder AC à tension à vide réduite. Dans la plupart des situations, l'utilisation d'un poste à souder DC à fil à tension constante est recommandée. En outre, ne pas travailler seul !
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
  - Installer le poste correctement et le mettre à la terre convenablement selon les consignes du manuel de l'opérateur et les normes nationales, provinciales et locales.
  - Toujours vérifier la terre du cordon d'alimentation. Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
  - En effectuant les raccordements d'entrée, fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
  - Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
  - Vérifier fréquemment le cordon d'alimentation afin de s'assurer qu'il n'est pas altéré ou à nu, le remplacer immédiatement s'il l'est. Un fil à nu peut entraîner la mort.
  - L'équipement doit être hors tension lorsqu'il n'est pas utilisé.
  - Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
  - Ne pas enrouler les câbles autour du corps.
  - Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct.
  - Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
  - Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
  - N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.
  - Porter un harnais de sécurité si l'on doit travailler au-dessus du sol.
  - S'assurer que tous les panneaux et couvercles sont correctement en place.
  - Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
  - Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
  - Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage.

## Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur UNE FOIS l'alimentation coupée.

- Arrêter les convertisseurs, débrancher le courant électrique et décharger les condensateurs d'alimentation selon les instructions indiquées dans la partie Entretien avant de toucher les pièces.



### LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher à mains nues les parties chaudes.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



### LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.


- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les spécifications de sécurité des matériaux (MSDS) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissants.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



### LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intense (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage approuvé muni de verres filtrants appropriés pour protéger visage et yeux pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter des vêtements confectionnés avec des matières résistantes et ignifuges (cuir, coton lourd ou laine) et des bottes de protection.



### LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Ne soudez pas si l'air ambiant est chargé de particules, gaz, ou vapeurs inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution, d'étincelles et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.



### DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.




### LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz comprimé en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



### Les CHAMPS ÉLECTROMAGNÉTIQUES (CEM) peuvent affecter les implants médicaux.


- Les porteurs de stimulateurs cardiaques et autres implants médicaux doivent rester à distance.
- Les porteurs d'implants médicaux doivent consulter leur médecin et le fabricant du dispositif avant de s'approcher de la zone où se déroule du soudage à l'arc, du soudage par points, du gougeage, de la découpe plasma ou une opération de chauffage par induction.



### LE BRUIT peut endommager l'ouïe.

Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvées pour les oreilles si le niveau sonore est trop élevé.



### LES BOUTEILLES peuvent exploser si elles sont endommagées.

Les bouteilles de gaz comprimé contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.


- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz comprimé, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Détourner votre visage du détendeur-régulateur lorsque vous ouvrez la soupape de la bouteille.
- Le couvercle du détendeur doit toujours être en place, sauf lorsque la bouteille est utilisée ou qu'elle est reliée pour usage ultérieur.
- Utiliser les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever et déplacer les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

## 2-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance



### Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




### L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Prévoir une période de refroidissement ; respecter le cycle opératoire nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.




### LA CHUTE DE L'ÉQUIPEMENT peut provoquer des blessures.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les chariots, les bouteilles de gaz ou tout autre accessoire.
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.
- Tenir l'équipement (câbles et cordons) à distance des véhicules mobiles lors de toute opération en hauteur.
- Suivre les consignes du Manuel des applications pour l'équation de levage NIOSH révisée (Publication N°94-110) lors du levage manuel de pièces ou équipements lourds.



### LES ÉTINCELLES PROJETÉES peuvent provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.



### LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.



### Les PIÈCES MOBILES peuvent causer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.




### LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gâchette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




### Les PIÈCES MOBILES peuvent causer des blessures.

- S'abstenir de toucher des organes mobiles tels que des ventilateurs.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Lorsque cela est nécessaire pour des travaux d'entretien et de dépannage, faire retirer les portes, panneaux, recouvrements ou dispositifs de protection uniquement par du personnel qualifié.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de rebrancher l'alimentation électrique.



### LIRE LES INSTRUCTIONS.


- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.



### LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.

- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



### LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.

- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

## 2-4. Proposition californienne 65 Avertissements

**⚠** Les équipements de soudage et de coupage produisent des fumées et des gaz qui contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des malformations congénitales et, dans certains cas, des cancers. (Code de santé et de sécurité de Californie, chapitre 25249.5 et suivants)

**⚠** Les batteries, les bornes et autres accessoires contiennent du plomb et des composés à base de plomb, produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation. Se laver les mains après manipulation.

**⚠** Ce produit contient des produits chimiques, notamment du plomb, dont l'État de Californie reconnaît qu'ils provoquent

des cancers, des malformations congénitales ou d'autres problèmes de procréation. *Se laver les mains après utilisation.*

Pour les moteurs à essence :

**⚠** Les gaz d'échappement des moteurs contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation.

Pour les moteurs diesel :

**⚠** Les gaz d'échappement des moteurs diesel et certains de leurs composants sont reconnus par l'État de Californie comme provoquant des cancers et des malformations congénitales ou autres problèmes de procréation.

## 2-5. Principales normes de sécurité

*Safety in Welding, Cutting, and Allied Processes*, ANSI Standard Z49.1, de Global Engineering Documents (téléphone : 1-877-413-5184, site Internet : [www.global.ihc.com](http://www.global.ihc.com)).

*Safe Practices for the Preparation of Containers and Piping for Welding and Cutting*, American Welding Society Standard AWS F4.1, de Global Engineering Documents (téléphone : 1-877-413-5184, site internet : [www.global.ihc.com](http://www.global.ihc.com)).

*National Electrical Code*, NFPA Standard 70, de National Fire Protection Association, Quincy, MA 02269 (téléphone : 800-344-3555, site Internet : [www.nfpa.org](http://www.nfpa.org) et [www.sparky.org](http://www.sparky.org)).

*Safe Handling of Compressed Gases in Cylinders*, CGA Pamphlet P-1, de Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (téléphone : 703-788-2700, site Internet : [www.cganet.com](http://www.cganet.com)).

*Safety in Welding, Cutting, and Allied Processes*, CSA Standard W117.2, de Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (téléphone : 800-463-6727, site internet : [www.csa-international.org](http://www.csa-international.org)).

*Safe Practice For Occupational And Educational Eye And Face Protection*, ANSI Standard Z87.1, de American National Standards Institute,

25 West 43rd Street, New York, NY 10036 (téléphone : 212-642-4900, site Internet : [www.ansi.org](http://www.ansi.org)).

*Standard for Fire Prevention During Welding, Cutting, and Other Hot Work*, NFPA Standard 51B, de National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (téléphone : 617-770-3000, site Internet : [www.nfpa.org](http://www.nfpa.org)).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, de U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (téléphone : 1-866-512-1800) (il y a 10 bureaux régionaux – le téléphone de la région 5, Chicago, est 312-353-2220, site Internet : [www.osha.gov](http://www.osha.gov)).

U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (téléphone : 301-504-7923, site internet : [www.cpsc.gov](http://www.cpsc.gov)).

*Applications Manual for the Revised NIOSH Lifting Equation*, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (téléphone : 1-800-232-4636, site internet : [www.cdc.gov/NIOSH](http://www.cdc.gov/NIOSH)).

## 2-6. Informations relatives aux CEM

Le courant électrique qui traverse tout conducteur génère des champs électromagnétiques (CEM) à certains endroits. Le courant de soudage crée un CEM autour du circuit et du matériel de soudage. Les CEM peuvent créer des interférences avec certains implants médicaux comme des stimulateurs cardiaques. Des mesures de protection pour les porteurs d'implants médicaux doivent être prises: par exemple, des restrictions d'accès pour les passants ou une évaluation individuelle des risques pour les soudeurs. Tous les soudeurs doivent appliquer les procédures suivantes pour minimiser l'exposition aux CEM provenant du circuit de soudage:

1. Rassembler les câbles en les torsadant ou en les attachant avec du ruban adhésif ou avec une housse.
2. Ne pas se tenir au milieu des câbles de soudage. Disposer les câbles d'un côté et à distance de l'opérateur.
3. Ne pas courber et ne pas entourer les câbles autour de votre corps.

4. Maintenir la tête et le torse aussi loin que possible du matériel du circuit de soudage.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.
6. Ne pas travailler à proximité d'une source de soudage, ni s'asseoir ou se pencher dessus.
7. Ne pas souder tout en portant la source de soudage ou le dévidoir.

### En ce qui concerne les implants médicaux :

Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction. Si le médecin approuve, il est recommandé de suivre les procédures précédentes.



# SECTION 3 – DEFINITIONS

## 3-1. Warning Label Definitions

1 Warning! Watch Out! There are possible hazards as shown by the symbols.

2 Electric shock from wiring can kill.

3 Overuse can cause overheating. Follow rated duty cycle.

4 Disconnect input plug or power before working on machine.

5 Become trained and read the instructions before working on the machine.

6 Connect green or green/yellow grounding conductor to ground terminal.

7 Connect input conductors (L1, L2 And L3) to line terminals.

Warning! Watch Out! There are possible hazards as shown by the symbols.


1 Electric shock from wiring can kill.
























2 Disconnect input plug or power before working on machine.

3 Turn power off before connecting to 115 volt receptacle.


4 Read the Owner's Manual

### 3-2. Symbol Definitions

 Some symbols are found only on CE products.

<b>A</b>	Amperage	<b>V</b>	Voltage	<b>Hz</b>	Hertz		Direct Current (DC)
	Alternating Current (AC)		Panel/Local		Line Connection		Three Phase
	Output	<b>I</b>	On		Voltage Input		Off
	Submerged Arc Welding (SAW)		Read Operator's Manual		Remote	<b>X</b>	Duty Cycle
<b>%</b>	Percent	<b>U<sub>0</sub></b>	Rated No-Load Voltage (Average)	<b>U<sub>1</sub></b>	Rated Supply Voltage		Circuit Breaker (Supplementary Protector)
<b>U<sub>2</sub></b>	Conventional Load Voltage	<b>I<sub>2</sub></b>	Rated Welding Current		Protective Earth (Ground)	<b>I<sub>1max</sub></b>	Rated Maximum Supply Current
<b>I<sub>1eff</sub></b>	Maximum Effective Supply Current		3-Phase Power Source With AC/DC Output		Temperature		Ventilating And Air Circulating Fan
	Increase/Decrease	<b>IP</b>	Degree Of Protection	<b>+</b>	Positive	<b>-</b>	Negative
	Fuse		Single Phase		Caution		Work Connection
	Electrode Connection		Frame Or Chassis	<b>TE</b>	Terminal Strip		

### 3-3. WEEE Label (For Products Sold Within The EU)



Do not discard product (where applicable) with general waste.

Reuse or recycle Waste Electrical and Electronic Equipment (WEEE) by disposing at a designated collection facility.

Contact your local recycling office or your local distributor for further information.



# SECTION 4 – INSTALLATION

## 4-1. Important Information Regarding CE Products (Sold Within The EU)

### A. Information On Electromagnetic Fields (EMF)

**⚠ This equipment shall not be used by the general public as the EMF limits for the general public might be exceeded during welding.**

This equipment is built in accordance with EN 60974-1 and is intended to be used only in an occupational environment (where the general public access is prohibited or regulated in such a way as to be similar to occupational use) by an expert or an instructed person.

Wire feeders and ancillary equipment (such as torches, liquid cooling systems and arc striking and stabilizing devices) as part of the welding circuit may not be a major contributor to the EMF. See the Owner's Manuals for all components of the welding circuit for additional EMF exposure information.

- The EMF assessment on this equipment was conducted at 0.5 meter.
- At a distance of 1 meter the EMF exposure values were less than 20% of the permissible values.

### B. Information On Electromagnetic Compatibility (EMC)

**⚠ This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility in those locations, due to conducted as well as radiated disturbances.**

IEC/TS 61000-3-4 may be used to guide the parties concerned by the installation of arc welding equipment with an input current above 75 Amps in a low-voltage network.

ce-emc 5 2010-10

## 4-2. Serial Number And Rating Label Location

The rating information for the power source is located on the front or the rear of the machine. Use the rating labels to determine input power requirements and/or rated output. The serial number is located on the front of the machine, for future reference, write serial number in space provided on back cover of this manual.

## 4-3. Specifications


AC or DC Rated Output	Voltage Range in CV Mode	Amperage Range in CC Mode	Max. Open- Circuit Voltage	IP Rating	RMS Amps Input at Rated Load Output, 3-Phase at NEMA Load Voltages and Class I Rating			KVA	KW
					380 V (50 Hz)	400V (50 Hz)	460 V (60 Hz)		
1000 A at 44 V, 100% Duty Cycle;	25-44 V	300-1250 A	71 V	IP21	140 (3*)	141 (3*)	122 (3*)	98 (2.37*)	53 (0.95*)
1250 A at 44 V, 60% Duty Cycle	25-44 V	300-1250 A	71 V		179 (3*)	176 (3*)	158 (3*)	122 (2.37*)	67 (0.95*)

\*While idling

## 4-4. Duty Cycle and Overheating



### 100% Duty Cycle At 1000 Amperes




Continuous Welding

Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

If unit overheats, high temperature shutdown light turns On, thermostat(s) opens, output stops, and cooling fan runs. Wait fifteen minutes for unit to cool. Reduce amperage or duty cycle before welding.

**NOTICE** – Exceeding duty cycle can damage unit and void warranty.

### Overheating



duty1 4/95 – 181 560


## 4-5. Dimensions And Weight

Dimensions	
Height*	44 in. (1118 mm)
Width*	27-1/4 in. (692 mm)
Depth*	46 in. (1168 mm)
A	1-7/8 in. (48 mm)
B	44-1/8 in. (1120 mm)
C	11/16 in. (17 mm)
D	26-1/16 in. (662 mm)
E	4 holes: 21/32 in. (6.5 mm) dia


**Weight**  
1180 lb (535 kg)

\* Includes lifting eye, handles, hardware, etc.


## 4-6. Selecting a Location



### Movement



OR



- 1 Lifting Eye
  - 2 Lifting Forks
- Use lifting eye or lifting forks to move unit.


If using lifting forks, extend forks beyond opposite side of unit.

- 3 Line Disconnect Device

Locate unit near correct input power supply.

**⚠ Special installation may be required where gasoline or volatile liquids are present – see NEC Article 511 or CEC Section 20.**

### Location



## 4-7. Weld Output Terminals And Selecting Cable Sizes\*

**NOTICE** – The Total Cable Length in Weld Circuit (see table below) is the combined length of both weld cables. For example, if the power source is 100 ft (30 m) from the workpiece, the total cable length in the weld circuit is 200 ft (2 cables x 100 ft). Use the 200 ft (60 m) column to determine cable size.


Welding Amperes	Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding***							
	100 ft (30 m) or Less	150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)	
	10 – 60% Duty Cycle AWG (mm <sup>2</sup> )	60 – 100% Duty Cycle AWG (mm <sup>2</sup> )	10 – 100% Duty Cycle AWG (mm <sup>2</sup> )					
100	4 (20)	4 (20)	4 (20)	3 (30)	2 (35)	1 (50)	1/0 (60)	1/0 (60)
150	3 (30)	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	3/0 (95)
200	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	4/0 (120)
250	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x2/0 (2x70)
300	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x3/0 (2x95)
350	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x3/0 (2x95)	2x4/0 (2x120)
400	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	2x4/0 (2x120)
500	2/0 (70)	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x3/0 (3x95)
600	3/0 (95)	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x4/0 (3x120)	3x4/0 (3x120)
700	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	3x4/0 (3x120)	3x4/0 (3x120)	4x4/0 (4x120)
800	4/0 (120)	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x4/0 (3x120)	3x4/0 (3x120)	4x4/0 (4x120)	4x4/0 (4x120)
900	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)				
1000	2x2/0 (2x70)	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)				
1250	2x3/0 (2x95)	2x4/0 (2x120)	3x3/0 (3x95)	4x3/0 (4x95)				
1500	600 (300)	750 (400)	1000 (500)	2x750 (2x400)				



### Weld Output Terminals


⚠ Turn off power before connecting to weld output terminals.

⚠ Do not use worn, damaged, undersized, or poorly spliced cables.



Electrode Weld Output Terminals      Work Weld Output Terminals

Requires cable lugs with 1/2 in. diameter holes.

 3/4 in.


\* This chart is a general guideline and may not suit all applications. If cable overheats, use next size larger cable.

\*\*Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere. ( ) = mm<sup>2</sup> for metric use


\*\*\*For distances longer than those shown in this guide, call a factory applications rep. at 920-735-4505 (Miller) or 1-800-332-3281 (Hobart).

Ref. S-0007-J 2011-07

## 4-8. Connecting Weld Output Cables




Correct Installation





Incorrect Installation

Tools Needed:





803 778-B

-  **Turn off power before connecting to weld output terminals.**
-  **Failure to properly connect weld cables may cause excessive heat and start a fire, or damage your machine.**

- 1 Weld Output Terminal
  - 2 Supplied Weld Output Terminal Nut
  - 3 Weld Cable Terminal
  - 4 Copper Bar
- Remove supplied nut from weld output terminal. Slide weld cable terminal onto weld


output terminal and secure with nut so that weld cable terminal is tight against copper bar. **Do not place anything between weld cable terminal and copper bar. Make sure that the surfaces of the weld cable terminal and copper bar are clean.**

## 4-9. Terminal Strip TE1, TE2 and Remote 14 Receptacle RC7 Information

	Socket on RC7	Terminal on TE2	Terminal on TE1	Information
24 VOLTS AC  OUTPUT (CONTACTOR)	A	-	-	24 volts, 12 amperes, AC. Protected by circuit breaker CB2.
	B	-	-	Contact closure to A completes 24 volts AC contactor control circuit.
REMOTE OUTPUT CONTROL	C	-	-	Command reference; +10 volts DC.
	D	-	-	Remote control circuit common.
	E	-	-	0 to +10 volts DC input command signal from remote control.
115 VOLTS AC  OUTPUT (CONTACTOR)	I	-	-	115 volts, 12 amperes AC. Protected by circuit breaker CB1.
	J	-	-	Contact closure to I completes 115 volts AC contactor control circuit.
GND	K	-	-	Chassis common.
	G	-	-	Circuit common for 24 and 115 volts AC circuits.
A/V AMPERAGE VOLTAGE	F	-	-	Current feedback; +1 volt DC per 100 amperes.
	H	-	-	Voltage feedback; +1 volt DC per 10 output terminal volts.
REMOTE VOLTAGE SENSING	*	N	-	Voltage sensing signal from Work weld output terminal.
	*	P	-	Voltage sensing signal from Electrode weld output terminal.
	-	TP	-	Test Point
	-	-	A	Used for synchronizing multiple AC arcs.
	-	-	C	Used for synchronizing multiple AC arcs.
	-	-	E	Used for synchronizing multiple AC arcs.



\* Not Used, - Not Applicable



 **Turn Off welding power source before opening access door.**

- 1 Access Door
- 2 Remote 14 Receptacle (Mounted Inside Access Area)
- 3 Terminal Strip TE2
- 4 Terminal Strip TE1
- 5 Remote Control

Connect remote control to Remote 14 receptacle.




247 476-C


## 4-10. Basic Sub Arc (SAW) Welding

☞ Customer must supply the following: power source, power source control cable, wire drive assembly, wire drive assembly cable, drive rolls, gun, welding wire, weld cables, remote voltage sense leads, and flux system for the desired application.

### A. Basic Sub Arc (SAW) Equipment Connections




## B. Remote Voltage Sensing Leads Placement Guidelines For A Single Arc (Required)



### **BAD**

Sense lead is affected by weld current.

Due to voltage drops across work piece, arc voltage may be low, causing need for deviation from standard procedures.



### **BEST**


Sense leads are out of the current paths.

Sense leads detect arc voltage accurately.

Best starts, arcs and most reliable results.




### C. Sensing Leads Placement Guidelines For Multiple Arcs




**BAD**

Current flow from lead affects trail sense.  
 Current flow from trail affects lead sense.  
 Neither sense lead picks up the correct work voltage, causing starting and welding arc instability.



**BETTER**



Lead sense is only affected by weld current from lead.  
 Trail sense lead is only affected by weld current from trail.  
 Due to voltage drops across work piece, arc voltage may be low, causing need for deviation from standard procedures.



**BEST**

Both sense leads are out of the current paths.  
 Both sense leads detect arc voltage accurately.  
 No voltage drop between lead and trail sense.  
 Best starts, arcs and most reliable results.



#### 4-11. 115 Volts AC Receptacle And Circuit Breaker 460 Volt Models



- 1 115 V 15 A AC Receptacle  
Power is shared between the duplex receptacle and the 115 volt output connections and the Remote 14 receptacle (see Section 4-9).
- 2 Supplementary Protector CB1  
CB1 protects 115 volts AC receptacle and Remote 14 receptacle from overload.

Ref. 175 086 / 247 477-C

#### 4-12. 230 Volts AC Receptacle And Circuit Breakers (400 Volt Input Models)



- 1 230 V 16 A AC Receptacle
- 2 Supplementary Protector CB1  
CB1 protects the Remote 14 receptacle from overload.
- 3 Supplementary Protector CB3  
CB3 protects the 230 volts AC receptacle from overload.

Ref. 175 086 / 247 478-C

## 4-13. Electrical Service Guide

### A. 1000 Models



Failure to follow these electrical service guide recommendations could create an electric shock or fire hazard. These recommendations are for a dedicated circuit sized for the rated output and duty cycle of the welding power source.

In dedicated circuit installations, the National Electrical Code (NEC) allows the receptacle or conductor rating to be less than the rating of the circuit protection device. All components of the circuit must be physically compatible. See NEC articles 210.21, 630.11, and 630.12.

	Three-Phase, 60 Hz
Input Voltage (V)	460
Input Amperes (A) At Rated Output	158
Max Recommended Standard Fuse Rating In Amperes <sup>1</sup>	
Time-Delay Fuses <sup>2</sup>	175
Normal Operating Fuses <sup>3</sup>	225
Min Input Conductor Size In AWG <sup>4</sup>	1
Max Recommended Input Conductor Length In Feet (Meters)	379 (115)
Min Grounding Conductor Size In AWG <sup>4</sup>	4

Reference: 2011 National Electrical Code (NEC) (including article 630)

- 1 If a circuit breaker is used in place of a fuse, choose a circuit breaker with time-current curves comparable to the recommended fuse.
- 2 "Time-Delay" fuses are UL class "RK5" . See UL 248.
- 3 "Normal Operating" (general purpose - no intentional delay) fuses are UL class "K5" (up to and including 60 amps), and UL class "H" ( 65 amps and above).
- 4 Conductor data in this section specifies conductor size (excluding flexible cord or cable) between the panelboard and the equipment per NEC Table 310.15(B)(16). If a flexible cord or cable is used, minimum conductor size may increase. See NEC Table 400.5(A) for flexible cord and cable requirements.

### B. 1250 Models



Failure to follow these electrical service guide recommendations could create an electric shock or fire hazard. These recommendations are for a dedicated circuit sized for the rated output and duty cycle of the welding power source.

In dedicated circuit installations, the National Electrical Code (NEC) allows the receptacle or conductor rating to be less than the rating of the circuit protection device. All components of the circuit must be physically compatible. See NEC articles 210.21, 630.11, and 630.12.


	Three-Phase, 50 Hz	
Input Voltage (V)	380	400
Input Amperes (A) At Rated Output	179	176
Max Recommended Standard Fuse Rating In Amperes <sup>1</sup>		
Time-Delay Fuses <sup>2</sup>	200	200
Normal Operating Fuses <sup>3</sup>	250	250
Min Input Conductor Size In AWG <sup>4</sup>	1/0	1/0
Max Recommended Input Conductor Length In Feet (Meters)	323 (98)	352 (107)
Min Grounding Conductor Size In AWG <sup>4</sup>	4	4

Reference: 2011 National Electrical Code (NEC) (including article 630)

- 1 If a circuit breaker is used in place of a fuse, choose a circuit breaker with time-current curves comparable to the recommended fuse.
- 2 "Time-Delay" fuses are UL class "RK5" . See UL 248.
- 3 "Normal Operating" (general purpose - no intentional delay) fuses are UL class "K5" (up to and including 60 amps), and UL class "H" ( 65 amps and above).
- 4 Conductor data in this section specifies conductor size (excluding flexible cord or cable) between the panelboard and the equipment per NEC Table 310.15(B)(16). If a flexible cord or cable is used, minimum conductor size may increase. See NEC Table 400.5(A) for flexible cord and cable requirements.



## 4-14. Connecting Input Power



**⚠** Installation must meet all National and Local Codes – have only qualified persons make this installation.

**⚠** Disconnect and lockout/tagout input power before connecting input conductors from unit.

**⚠** Make input power connections to the welding power source first.

**⚠** Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.

**⚠** When using multiple units which will be linked with the synchronizing terminal strip TE1, ensure that primary input power conductors are connected to each unit in the same sequence (L1 to L1, L2 to L2, and L3 to L3.)

☞ See Section 4-15 for information on testing for proper primary phase sequence.

See rating label on unit and check input voltage available at site.

Open rear panel access door.

1 Input Power Conductors (Customer Supplied Cord)

Select size and length of conductors using Section 4-13. Conductors must comply with national, state, and local electrical codes. If applicable, use lugs of proper amperage capacity and correct hole size.

### Welding Power Source Input Power Connections

- 2 Machine Grounding Terminal
- 3 Green Or Green/Yellow Grounding Conductor

Connect green or green/yellow grounding conductor to welding power source grounding terminal first.

- 4 Welding Power Source Line Terminals
- 5 Input Conductors L1 (U), L2 (V) And L3 (W)

Connect input conductors L1 (U), L2 (V) and L3 (W) to welding power source line terminals.

Close and secure rear panel access door.

### Disconnect Device Input Power Connections

- 6 Disconnect Device (switch shown in OFF position)
- 7 Disconnect Device (Supply) Grounding Terminal

Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.

- 8 Disconnect Device Line Terminals


Connect input conductors L1 (U), L2 (V) And L3 (W) to disconnect device line terminals.

- 9 Overcurrent Protection

Select type and size of overcurrent protection using Section 4-13 (fused disconnect switch shown).

Close and secure door on line disconnect device. Remove lockout/tagout device, and place switch in the On position.

## 4-15. Matching Primary Lines L1, L2, And L3 When Using Multiple AC Units



**⚠ Only qualified persons should install, operate, maintain, and repair this unit.**

This test must be performed on the units that will be interconnected using the test point (TP) terminal strip TE2. This refers to the multiple unit hook-ups shown in Section 5-2.

Turn power On to both units. Use an AC voltmeter to measure the voltage between terminal TP of terminal strip TE2 on both units as shown.

If the measured voltage is approximately 0 (zero) volts, the primary lines are properly phased.


**⚠ Turn off welding power source and disconnect and lockout/tagout input power before changing connections at primary input contactor.**

If the measured voltage is approximately 53 volts, swap the input conductor connections to L1 and L3 on the primary input contactor of unit B.

If the measured voltage is approximately 46 volts, swap L1 and L2 on the primary input contactor of unit B. The meter will then read either approximately 53 volts or approximately 26 volts. If the meter reads approximately 53 volts, swap L1 and L3. If the meter reads approximately 26 volts, swap L2 and L3.


If the measured voltage is approximately 26 volts, swap L1 and L2 on the primary input contactor of unit B. The meter will then read either approximately 0 (zero) volts or approximately 46 volts. If the meter reads approximately 0 volts, the primary lines are properly phased. If the meter reads approximately 46 volts, swap L1 and L2 again, and swap L2 and L3.

When the second unit's primary line phase sequences are matched with the first unit, test primary phasing between third unit (if applicable) and second unit. Always test and correct phasing between following unit and unit previous to it.



# SECTION 5 – MAKING WELD OUTPUT CONNECTIONS

## 5-1. Work And Electrode Cable Connections For Single DC or AC Arcs




**⚠ Turn Off welding power source before opening access door.**


**NOTICE** – If there are any questions regarding this procedure, contact the factory before connecting units.

Connect the proper size and number of weld output cables (see Section 4-7) to one or more of the welding power source electrode terminals.


Connect the proper size and number of ground cables to one or more of the welding power source work terminals.



## 5-2. Connecting Multiple Units



### Non-Parallel Connections




**⚠ Turn Off welding power source before opening access door.**

**NOTICE** – This procedure is not for paralleling. Refer to connection below for paralleling procedures. Severe damage to units may occur if units are not correctly connected for parallel operation.

To use two or more AC arcs with separate electrodes, make connections as shown.

Set up AC output units according to Section 5-3.

### Parallel Connections



**⚠ Turn Off welding power source before opening access door.**

**NOTICE** – If there are any questions regarding the paralleling procedure, contact the factory before connecting units. Severe damage to units may occur if units are not correctly connected for parallel operation.

To use two or more units with one electrode, make connections as shown.

Set up AC output units according to Section 5-3.

**☞** The first unit controls voltage. All remaining units supply additional current.

1 Power/Balance Control

**NOTICE** – All units being paralleled must be set to the same balance (see Section 6).

2 CC/CV Switch

**NOTICE** – All units being paralleled must be in CC position (see Section 6).

**☞** When running multiple units in parallel, Parallel Controller (Miller part number 194711) must also be used. Install controller according to instructions provided with unit.

**☞** Although all units are set in the CC position, the paralleled process runs in constant voltage.



247 476-C



### 5-3. Using AC Arcs Terminal Strip TE1 Connections



Tools Needed:



**⚠ Turn Off welding power source before opening access door.**

**ℹ DC output units do not require synchronization with AC output units.**

**NOTICE** – All units must be set to the same balance (see Section 6) when multiple units are connected in AC.

**NOTICE** – If there are any questions regarding the paralleling procedure, contact the factory before connecting units. Severe damage to units may occur if units are not correctly connected for parallel operation.

#### 1 Terminal Strip TE1

This procedure allows the AC output waveforms of two or more units to have the correct phase shift. Make connections between terminal strip TE1 on applicable AC output units as shown in illustration.


**ℹ Do not disturb factory connections to terminal strip TE1.**

**⚠ Ensure that primary input power conductors are connected to each unit in the same sequence (L1 to L1, L2 to L2, and L3 to L3). See Section 4-14 for information on connecting input power. See Section 4-15 for information on testing for proper primary phase sequence.**


#### 2 Lead Being Connected To TE1

Strip 3/8 in. (10 mm) insulation off end of lead. Press tab in slot with screwdriver or similar device, insert end of lead into proper location on TE1 and release tab.

Close and secure access door.




**ℹ Use two-conductor (12 to 20 gauge) with uninsulated ground, shielded cable to make TE1 connections. Connect uninsulated ground wire to terminal C on TE1.**



Connections from first to second welding power source:  
terminal A to terminal E,  
terminal C to terminal C

Connections from second to third welding power source:  
terminal A to terminal E,  
terminal C to terminal C

Connections from third to fourth welding power source:  
terminal A to terminal E,  
terminal C to terminal C



Repeat same connection sequence on following welding power sources

**Terminal Strip TE1 Connections For Running Multiple AC Arcs**

Ref. 247 476-C

# SECTION 6 – OPERATION

## 6-1. Front Panel Controls For Non-CE Models



### 1 Output Control Switch

For weld output, place switch in On position. For remote control of output, make connections to Remote 14 receptacle (see Section 4-9) and place switch in Remote position.

### 2 Output On LED

**⚠ Output is on and weld output studs are energized when LED is lit.**

### 3 A/V (Amperage/Voltage) Control Switch

For front panel control, place switch in Panel position and use the A/V Adjust control.

**⚠ Turn Off power before connecting remote device.**

For remote control, connect remote device to Remote 14 receptacle, and place switch in Remote position. Remote control provides full range of unit output regardless of A/V Adjust

control setting

### 4 A/V (Amperage/Voltage) Adjustment Control

Use control to select weld voltage when CC/CV switch is in the CV position, or amperage when CC/CV switch is in the CC position. Control may be adjusted while welding. Numbers on scale are for reference only.

### 5 Terminal TE1

To run a single machine in the CC mode, jumper terminal A to E on TE1.

### 6 Power/Balance Control

Use control to select Direct Current Electrode Positive (DCEP – EP), or Direct Current Electrode Negative (DCEN – EN), or select one of the following AC Balance/Frequency combinations: 80/20-18 Hz, 60/40-18 Hz, 50/50-90 Hz, 50/50-10 Hz,

40/60-18 Hz, 33/67-60 Hz, 30/70-18 Hz, or 20/80-18 Hz.

### 7 Power Switch w/Indicator Light

8 High Temperature Shutdown Light  
See Section 4-4.


*The fan motor is thermostatically controlled and only runs when cooling is needed.*

### 9 CC/CV Switch

Switch is mounted on electronics baffle.

**⚠ Turn Off welding power source and disconnect lockout/tagout input power before removing cover to change switch position.**

Place switch in desired position and install cover.



Ref. 246 002-D / 248 485-B / Ref. 247 476-C

## 6-2. Front Panel Controls For CE Models



### 1 Output Control Switch

For weld output, place switch in On position. For remote control of output, make connections to Remote 14 receptacle (see Section 4-9) and place switch in Remote position.

### 2 Output On LED

**⚠ Output is on and weld output studs are energized when LED is lit.**

### 3 A/V (Amperage/Voltage) Control Switch

For front panel control, place switch in Panel position and use the A/V Adjust control.

**⚠ Turn Off power before connecting remote device.**

For remote control, connect remote device to Remote 14 receptacle, and place switch in Remote position. Remote control provides full range of unit output regardless of A/V Adjust

control setting

### 4 A/V (Amperage/Voltage) Adjustment Control

Use control to select weld voltage when CC/CV switch is in the CV position, or amperage when CC/CV switch is in the CC position. Control may be adjusted while welding. Numbers on scale are for reference only.

### 5 Terminal TE1

To run a single machine in the CC mode, jumper terminal A to E on TE1.

### 6 Power/Balance Control

Use control to select Direct Current Electrode Positive (DCEP – EP), or Direct Current Electrode Negative (DCEN – EN), or select one of the following AC Balance/Frequency combinations: 80/20-15 Hz, 70/30-15 Hz, 67/33-50 Hz, 60/40-15 Hz, 50/50-75 Hz, 50/50-8 Hz, 40/60-15 Hz, 33/67-50 Hz, 30/70-15 Hz, 20/80-15 Hz.

40/60-15 Hz, 33/67-50 Hz, 30/70-15 Hz, or 20/80-15 Hz.

### 7 Power Switch w/Indicator Light

### 8 High Temperature Shutdown Light

See Section 4-4.


**☞ The fan motor is thermostatically controlled and only runs when cooling is needed.**

### 9 CC/CV Switch

Switch is mounted on electronics baffle.

**⚠ Turn Off welding power source and disconnect lockout/tagout input power before removing cover to change switch position.**

Place switch in desired position and install cover.



**Miller.**  
**SubArc AC/DC 1250**

Ref. 246 334-E / 248 443-C / Ref. 247 476-C

# SECTION 7 – MAINTENANCE AND TROUBLESHOOTING

## 7-1. Routine Maintenance

				<b>⚠ Disconnect input power before maintaining.</b>		<i>Maintain more often during severe conditions.</i>
	✓ = Check ◇ = Change ● = Clean * To be done by Factory Authorized Service Agent			Δ = Repair	☆ = Replace	
Every 3 Months	 ✓☆ Labels	 ☆ Cracked Parts	 Δ ☆ Cracked Cables			
Every 3 Months						
Every 3 Months						
Every 6 Months						

## 7-2. Fuse F1

			<b>⚠ Turn Off welding power source and disconnect lock-out/tagout input power before checking fuse.</b>
--	--	--	---

Fuse F1 protect the 115 volt AC winding of transformer T2. If fuse F1 opens, the welding power source shuts down.

Open rear panel access door to access fuses.

1 Fuse F1

Check F1 and replace if needed, using a fuse of the same rating.

Close and secure rear panel access door.

Tools Needed:

 3/8 in.


247 479-B

### 7-3. Access Area Supplementary Protectors




**⚠ Turn Off welding power source before checking circuit breakers.**

- 1 Supplementary Protector CB2  
CB2 protects the 24 VAC portion of the Remote 14 receptacle.  
Press button to reset breaker.




247 476-C

### 7-4. Troubleshooting



Trouble	Remedy
No weld output; unit completely inoperative.	Place line disconnect switch in On position (see Section 4-14).
	Check fuse F1 and replace if necessary (see Section 7-2).
	Check and replace line fuse(s), if necessary, or reset circuit breaker (see Section 4-14).
	Check for proper input power connections (see Section 4-14).
No weld output; pilot light On.	Check, repair, or replace remote control.
	Unit overheated. Allow unit to cool with fan On (see Section 4-4).
	Have Factory Authorized Service Agent check control board PC1.
Erratic or improper weld output.	Use proper size and type of weld cable (see Section 4-7).
	Clean and tighten all weld connections.
	When using multiple units, make sure all units connected with terminal strip TE1 are turned on.
	Have Factory Authorized Service Agent check control board PC1.
No 115 volts AC output at duplex receptacle and Remote 14 receptacle.	Reset supplementary protector CB1 (see Section 4-11).
No 230 volts AC output at duplex receptacle.	Reset supplementary protector CB3 (see Section 4-12).
No 24 volts AC output at Remote 14 receptacle.	Reset supplementary protector CB2 (see Section 7-3).

# SECTION 8 – ELECTRICAL DIAGRAMS

	<b>WARNING</b>
	<ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Disconnect input power or stop engine before servicing.</li> <li>Do not operate with covers removed.</li> <li>Have only qualified persons install, use, or service this unit.</li> </ul>
<b>ELECTRIC SHOCK HAZARD</b>	






Figure 8.1. Circuit Diagram For Sub Arc AC/DC 1000 (460 V Input) Model



- TE1  
A O 99  
C O 33  
E O 102
- TE2  
TEST POINT O 84  
N O 27  
P O 28

 <b>⚠ WARNING</b> <b>ELECTRIC SHOCK HAZARD</b>	<ul style="list-style-type: none"> <li>Do not touch live electrical parts.</li> <li>Disconnect input power or stop engine before servicing.</li> <li>Do not operate with covers removed.</li> </ul>
	<ul style="list-style-type: none"> <li>Have only qualified persons install, use, or service this unit.</li> </ul>

SEE RATING LABEL FOR INPUT VOLTAGE







Figure 8.2. Circuit Diagram For Sub Arc AC/DC 1250 (400 V Input) Model





# SECTION 9 – PARTS LIST



 Hardware is common and not available unless listed.

 1000 Model Illustrated

247 435-D

**Figure 9-1. Main Assembly**


Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------


**Figure 9-1. Main Assembly**

.. 1		246960	.. Panel, Side	2
.. 2		+245938	.. Cover,Top	1
.. 3		217136	.. Label, Warning Electric Shock(Eng/Fr)	1
.. 3		176254	.. Label, General Precautionary Wordless Intl	1
.. 4		184340	.. Channel, Upright	4
.. 5		026627	.. Gasket, Lift Eye	1
.. 6		184344	.. Stop, Cover	1
.. 7		184342	.. Lift Eye	1
.. 8		184341	.. Bar, Cross Lift Eye	2
.. 9		Fig.9-3	.. Panel, Rear	1
.. 10	Z1	184350	.. Stabilizer	1
.. 11		184359	.. Bracket, Mtg Terminal Assy	2
.. 12	T1	246546	.. Xfmr Assy, Power Main 460 V Model	1
.. 12	T1	246550	.. Xfmr Assy, Power Main 400 V Model	1
.. 13		246874	.. Base,	1
.. 14		184345	.. Bracket, Rectifier	1
.. 15	SR1	246263	.. Rectifier, SCR Main	1
.. 16		Fig. 9-2	.. Panel, Front	1

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

**To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.**

 Hardware is common and not available unless listed.



 1000 Model Illustrated

247 433-D

**Figure 9-2. Front Panel Assembly**

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
<b>Figure 9-2. Front Panel Assembly (Figure 9-1 Item 16)</b>				
1		245321	Cover, Receptacle Weatherproof Duplex Rcpt	1
2		248445	Strip, Polycarbonate Clear .250 X 6.000 X 12.500	1
3		248446	Latch, Cam	1
4			Nameplate, (Order By Model And Serial Number)	1
5		248467	Panel, Front	1
6	RC1	604176	Rcpt, Str Dx Grd 2p3W 15A 125V *5-15r (460 V Models)	1
6	RC1	176355	Rcpt, Str 2p3W 16A 220V Flange Mtg (400 V Models)	1
7	PL3	249340	LED Assy, Blue w/Terminals	1
8	S2	248658	Switch, Rocker SPST 15/10A 125/250VAC On-None-On Spd Term Blk	1
9	S4	252263	Switch, Rocker 2PDT 15/10A 125/250VAC On-None-On	1
10		171007	Knob, Pointer 1.670 Dia X .250 ID W/Set Screwplstc	1
11		174991	Knob, Pointer 1.250 Dia X .250 ID W/Spring Clip-.21	1
12			Nameplate, Recessed (Order By Model And Serial Number)	1
13	S5	246169	Switch, Rotary Multi-deck 12posn 1/4Amp PC Mtg	1
14	R5	030109	Pot, Cp Std Slot 1t 2. W 5k Linear	1
15		248442	Panel, Recessed	1
16	CB1-2	093995	Supplementary Pro,Man Reset 1p 15A 250VAC Frict (460 V Models)	2
16	CB1-3	093995	Supplementary Pro,Man Reset 1p 15A 250VAC Frict (400 V Models)	3
17		246369	Bracket, Mtg Receptacle (115V) (460 V Models)	1
17		246370	Bracket, Mtg Receptacle (230V) (400 V Models)	1
18		170647	Bushing, Snap-In Nyl 1.312 ID X 1.500 Mtg Hole	3
19	PC1	244419	Circuit Card Assy, Control W/Program	1
	PLG11	163467	Housing Plug+Skts, (Service Kit)	1
	PLG12,13,15	152249	Housing Plug Pins+Skts, (Service Kit)	3
	PLG14	115094	Housing Plug+Skts, (Service Kit)	1
20		098691	Stand-off, No 6-32 X .500 Lg .250 Hex Stl M&F	4
21		244732	Baffle, Electronics	1
22	HD2	244958	Transducer, Current 1000A Module Supply V +/- 15V	1
23		245940	Bracket, Mtg LEM	1
24	CR1	000174	Relay, Encl 24VAC 3PDT 10A/120VAC 11Pin Flange Mtg	1
25	R3,4	136076	Resistor, WW FXD 30W 200 Ohm Faston Te	2
26	C19, 20	249477	Capacitor Assy	2
27	RC7	134735	Conn, Circ MS/CPC 14Skt Size 20 Rcpt Panel Pushin	1
28	C9, 10	246168	Capacitor Assy	2
29		190960	Terminal Assy, Power Output (Includes)	2
		601840	Nut, 500-13 .88hex .32h Brs	4
		191137	Bus Bar, Terminal Power Output	1
		191138	Terminal Board, Power Output	1
		601839	Nut, 500-13 .75hex .44h Brs	2
		038900	Stud, Brs .500-13 X 2.250	2
		602247	Washer, Flat .531ID x 1.062OD x .095t Stl Pld ANSI.500	2
		605787	Washer, Tooth.512 ID x 0.900 OD x .045 T Stl Pld Int.500 A	2
30		010546	Bushing, Snap-In Nyl .375 ID X .500 Mtg Hole	2
31	S3	011609	Switch, Tgl Spdt 15A 125VAC On-none-on Spd Term Chr	1
32		246099	Bracket, Mtg Term Assy	1
33		005107	Bolt, Crg Stl .250-20 X .750 Gr5 Pld	8
34	TE2	246951	Block, Term 20 Amp 3 Pole Quick Conn 20-12AWG Wire Labeled	1
35	TE1	246950	Block, Term 20 Amp 3 Pole Quick Conn 20-12AWG Wire Labeled	1
36		246170	Nameplate, SUBARC AC/DC 1000/1250 Lower	1
37		161303	Spring, CPRSN .600 OD X .072 Wire X 1.500 Pld	3
38		+172587	Cover, Output Stud Generic	1
39		160935	Clip, Spring	3
40		217861	Label, Warning Electric Shock Can Kill Etc (FR) (460 V Model)	1
40		194557	Label, Warning Electric Shock Can Kill Etc Wordless (400 V Models)	1
41	S1	248654	Switch, Rocker SPST 15/10A 125/250VAC 28V Wht Lamp Off-None-On Spd Term Blk	1


Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

**Figure 9-2. Front Panel Assembly (Figure 9-1 Item 16) (continued)**

... 42	... PL2	... 247090	.. LED Assy, Yellow W/Terminals	1
... 43	.....	... 168343	.. Hinge, Cont Polypropylene Copolymer 2.000 L W/.125	2
... 44	.....	... 248450	.. Latch, Lock w/Key (Wing Style)	1

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

**To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.**



**Figure 9-3. Rear Panel Assembly**

247 434-C

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
<b>Figure 9-3. Rear Panel Assembly (Figure 9-1 Item 9)</b>				
... 1	FM	032605	Motor, Cap Perm SP 1/4HP 230VAC 1625RPM	1
... 2	CR2	006393	Relay, Encl 24VAC DPDT 10A/120VAC 8Pin Flange Mtg	1
... 3		222352	Windtunnel, 20 in	1
... 4	R1,2	097459	Resistor, WW FXD 375 W 20 Ohm	2
... 5		222347	Blade, Fan 20.000 3WG 13DEG .500 Bore CW AL	1
... 6		+245936	Panel, Rear	1
... 7		218280	Hinge, Cont Polyolefin Copolymer 2.000 L W/.125H	3
... 8		245937	Door, Primary Access	1
... 9		217860	Label, Warning Electric Shock And Input Pwr (FR)	1
... 9		252157	Label, Warning Electric Shock And Input Power (CE)	1
... 10	W	252348	Contact, Size S3 3P AC 140 Amp 24V 50/60 Hz	1
...	W1	213446	Interlock, Cntor No Size 3-1/2	1
... 11		252264	Spacer	2
... 12		252349	Rail, Din	1
... 13		252265	Block, Power Splice 3P 175 Amp 600V AC/DC	1
... 14		159034	Holder, Fuse Mintr 10.3mm X 33.3 To 38.1mm Panel Mt	1
... 15		156065	Fuse, Crtg .5 Amp 600V Time Delay	1
... 16		030170	Bushing, Snap-in Nyl .750 ID X 1.000 Mtg Hole	1
... 17		246208	Bracket, Mtg Contactor	1
... 18	T2	246003	Xfmr, Control 100VA 24V 460V Pri 60Hz (460 V Models)	1
... 18	T2	246602	Xfmr, Control 100VA 24V 400V Pri 50Hz (400 V Models)	1
... 19		188403	Bracket, Mtg LEM	1
... 20	HD1	148417	Transducer, Current 1000A Module Supply V +/- 24V	1
... 21		134201	Stand-Off Support, PC Card .312/.375W/Post & Lock .43	4

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

**To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.**









# TRUE BLUE<sup>®</sup>

## WARRANTY

Effective January 1, 2011

(Equipment with a serial number preface of MB or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

### Warranty Questions?

Call  
1-800-4-A-MILLER  
for your local  
Miller distributor.

Your distributor also gives  
you ...

#### Service

You always get the fast,  
reliable response you  
need. Most replacement  
parts can be in your  
hands in 24 hours.

#### Support

Need fast answers to the  
tough welding questions?  
Contact your distributor.  
The expertise of the  
distributor and Miller is  
there to help you, every  
step of the way.

**LIMITED WARRANTY** – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the delivery date of the equipment to the original end-user purchaser, and not to exceed one year after the equipment is shipped to a North American distributor or eighteen months after the equipment is shipped to an International distributor.

1. 5 Years Parts — 3 Years Labor
  - \* Original main power rectifiers only to include SCRs, diodes, and discrete rectifier modules
2. 3 Years — Parts and Labor
  - \* Engine Driven Welding Generators  
**(NOTE: Engines are warranted separately by the engine manufacturer.)**
  - \* Inverter Power Sources (Unless Otherwise Stated)
  - \* Plasma Arc Cutting Power Sources
  - \* Process Controllers
  - \* Semi-Automatic and Automatic Wire Feeders
  - \* Smith 30 Series Flowgauge and Flowmeter Regulators (No Labor)
  - \* Transformer/Rectifier Power Sources
  - \* Water Coolant Systems (Integrated)
3. 2 Years — Parts
  - \* Auto-Darkening Helmet Lenses (No Labor)
4. 1 Year — Parts and Labor Unless Specified
  - \* Automatic Motion Devices
  - \* CoolBelt and CoolBand Blower Unit (No Labor)
  - \* External Monitoring Equipment and Sensors
  - \* Field Options  
**(NOTE: Field options are covered for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)**
  - \* Flowgauge and Flowmeter Regulators (No Labor)
  - \* RFCS Foot Controls (Except RFCS-RJ45)
  - \* Fume Extractors
  - \* HF Units
  - \* ICE Plasma Cutting Torches (No Labor)
  - \* Induction Heating Power Sources, Coolers, and Electronic Controls/Recorders
  - \* Load Banks
  - \* Motor Driven Guns (w/exception of Spoolmate Spoolguns)
  - \* PAPR Blower Unit (No Labor)
  - \* Positioners and Controllers
  - \* Racks
  - \* Running Gear/Trailers
  - \* Spot Welders
  - \* Subarc Wire Drive Assemblies
  - \* Water Coolant Systems (Non-Integrated)
  - \* Weldcraft-Branded TIG Torches (No Labor)
  - \* Wireless Remote Foot/Hand Controls and Receivers
  - \* Work Stations/Weld Tables (No Labor)

5. 6 Months — Parts
  - \* Batteries
  - \* Bernard Guns (No Labor)
  - \* Tregaskiss Guns (No Labor)

6. 90 Days — Parts
  - \* Accessory (Kits)
  - \* Canvas Covers
  - \* Induction Heating Coils and Blankets, Cables, and Non-Electronic Controls
  - \* M-Guns
  - \* MIG Guns and Subarc (SAW) Guns
  - \* Remote Controls and RFCS-RJ45
  - \* Replacement Parts (No labor)
  - \* Roughneck Guns
  - \* Spoolmate Spoolguns

Miller's True Blue<sup>®</sup> Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, relays, work station table tops and welding curtains, or parts that fail due to normal wear. (Exception: brushes and relays are covered on all engine-driven products.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.





# Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



## For Service

**Contact a DISTRIBUTOR or SERVICE AGENCY near you.**

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Personal Safety Equipment

Service and Repair

Replacement Parts

Training (Schools, Videos, Books)

Technical Manuals (Servicing Information and Parts)

Circuit Diagrams

Welding Process Handbooks

To locate a Distributor or Service Agency visit [www.millerwelds.com](http://www.millerwelds.com) or call 1-800-4-A-Miller

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

### Miller Electric Mfg. Co.

An Illinois Tool Works Company  
1635 West Spencer Street  
Appleton, WI 54914 USA

### International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended  
USA & Canada FAX: 920-735-4134  
International FAX: 920-735-4125

For International Locations Visit  
[www.MillerWelds.com](http://www.MillerWelds.com)

