



Parallel connection of LAF-welding power source



Master



Slave

Instruction manual

ENGLISH 3

Rights reserved to alter specifications without notice.

1 SAFETY	4
2 INTRODUCTION	7
2.1 General	7
2.2 Connection instructions for two parallel-connected welding power sources and one PEK control box	8
3 Location Drawing	9
3.1 Location drawing - Welding Power Source LAF 631	9
3.2 Location drawing - Welding Power Source LAF 1001	10
3.3 Location drawing - Welding Power Source LAF 1251/1601	11
4 Connection in Parallel Using Six-Thyristor Operation	12
DIAGRAM	14
SPARE PARTS LIST	17

1 SAFETY

Users of ESAB welding equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of welding equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the welding equipment.

Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the welding equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up.
 - no-one is unprotected when the arc is struck
3. The workplace must:
 - be suitable for the purpose
 - be free from draughts
4. Personal safety equipment
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves. **Note!** *Do not use safety gloves when replacing wire.*
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
 - Make sure the return cable is connected securely.
 - Work on high voltage equipment **may only be carried out by a qualified electrician.**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
 - Lubrication and maintenance must **not** be carried out on the equipment during operation.



WARNING



ARC WELDING AND CUTTING CAN BE INJURIOUS TO YOURSELF AND OTHERS. TAKE PRECAUTIONS WHEN WELDING. ASK FOR YOUR EMPLOYER'S SAFETY PRACTICES WHICH SHOULD BE BASED ON MANUFACTURER'S HAZARD DATA.

ELECTRIC SHOCK - Can kill

- Install and earth the welding unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to keep fumes and gases from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

NOISE - Excessive noise can damage hearing

- Protect your ears. Use ear defenders or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION

- Call for expert assistance in the event of malfunction.


READ AND UNDERSTAND THE INSTRUCTION MANUAL BEFORE INSTALLING OR OPERATING.

PROTECT YOURSELF AND OTHERS!



CAUTION!

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.



WARNING!

Read and understand the instruction manual before installing or operating.



Do not dispose of electrical equipment together with normal waste!

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical equipment that has reached the end of its life must be collected separately and returned to an environmentally compatible recycling facility. As the owner of the equipment, you should get information on approved collection systems from our local representative.

By applying this European Directive you will improve the environment and human health!

CAUTION!

The welding power source and control box PEH can't be used together.


2 INTRODUCTION

2.1 General

Connection in parallel can be done with all sizes of the LAF welding power source. The current outlet from each welding power source depends on its size, see below.

The mains connection is to be done in the same way for **Master** and **Slave**.


It is possible to use the so-called six-thyristor effect by inverting the primary terminal of the main transformer, see page 12.



Connection in Parallel of Welding Power Sources of the Same Size

Connection in Parallel of Welding Power Sources of Different Size


When the welding power sources are of different size the smallest one is to be **Master**.



Current Outlet for Welding Power Sources of the Same Size

If the power sources are of the same size the current outlet will be evenly distributed.


- *1 Max = 1600 A
- *2 500+500 = 1000 A



Current Outlet for Welding Power Sources of Different Sizes

If the Welding power sources are of different sizes the current outlet will be procentually evenly distributed.

- *1 Max = 1000+600= 1600 A
- *2 500+300 = 800 A




2.2 Connection instructions for two parallel-connected welding power sources and one PEK control box

1. Emergency stop coil **W01**, is connected together with the enclosed contact block, which in turn has been fitted on **KM2**, in accordance with the diagram on page 14 (automatic welding machine) or page 15 (automation).
2. On the welding power source defined as Slave **CN18** (pin 1 and 2), on **AP1**, shall be clamped for analogue control.
3. Start up both welding power sources and connect **ESAT** to the **Master** welding power source.
4. Set parameter **762** to **1**, Master searches for the welding power source selected as Slave.
5. Set parameter **767** to **10**, Node address on the welding power source selected as Slave.
6. Move the **ESAT** connection to the welding power source defined as **Slave**.
7. Set parameter **10** to **16**, Slave function.
8. Set parameter **67** to **0**, with value 1 so the welding power source expects an analogue signal.
9. Set parameter **712** to **0**, the wire feed is not controlled by the welding power source defined as Slave.
10. Set parameter **713** to **0**, the travel motor is not controlled by the welding power source defined as Slave.
11. Set parameter **762** to **0**, Slave does not search for another power source.
12. Set parameter **767** to **2**, Node address on the welding power source defined as Master.
13. Set parameter **9000** to **10**, Node address for the welding power source defined as Slave.
14. Switch off the voltage to both welding power sources.
15. Remove the clamp on **CN18** (pin 1 and 2) on the Slave welding power source.
16. Remove the clamp on **CN11** on the Master welding power source.
17. Connect cable **W02** to the welding power sources.
18. Switch on the voltage to the Slave welding power source.
19. Switch on the voltage to the Master welding power source.
20. Check that the emergency stop coil is working, both the welding power sources (emergency stop relay/emergency stop contactors) are switched off. After resetting, the welding power sources start up normally and are ready for use.
21. Check that the parallel current value can be set in **PEK**.


For more information on component location on the circuit board, see the service manual for the LAF welding power source.

3 Location Drawing


3.1 Location drawing - Welding Power Source LAF 631



3.2 Location drawing - Welding Power Source LAF 1001




3.3 Location drawing - Welding Power Source LAF 1251/1601




4 Connection in Parallel Using Six-Thyristor Operation

In this case the Master/Slave welding power sources are connected to the mains by way of six thyristors (three in each welding power source). This results in softer welding current as the phase shift is 60° instead of 120° .


- Connection of Master+Slave using the six-thyristor effect. Note that the primary winding of the Slave is reversed.



- The phase shift goes down from 120° to 60° , see the diagrams below.



- The following sine-wave diagram shows the equalising effect obtained when using inversion of the Slave transformer.




The requirement is that the welding power sources are of the same size, and that it is possible to shift the input and output on the primary side of the main transformer. This is easily done on LAF 1001, 1251 and 1601, whereas it is more complicated on LAF 631, as the winding of the transformer is connected directly to the main contactor.

IMPORTANT!


Connect the right winding. Most power sources have more than one mains voltage. This applies particularly to machines designed for different mains voltages.

Below you find examples how to connect master and slave to the mains when using power sources without multivoltage connections.




DIAGRAM

Tractor variant



Automation variant



SPARE PARTS LIST

Edition 101001

Ordering no.	Denomination	Notes
0808573882	Parallel connection kit	

Item no.	Qty	Ordering no.	Denomination	Notes
		0808573882	Parallel connection kit	LAF-PEK
W01	4	0801389053	Cable	4x2x0.5, liycy
W02	1	0458681908	Cable	L=4 m
	1	0436919007	Auxillary contact block	

ESAB subsidiaries and representative offices

Europe AUSTRIA ESAB Ges.m.b.H Vienna-Liesing Tel: +43 1 888 25 11 Fax: +43 1 888 25 11 85 BELGIUM S.A. ESAB N.V. Brussels Tel: +32 2 745 11 00 Fax: +32 2 745 11 28 BULGARIA ESAB Kft Representative Office Sofia Tel/Fax: +359 2 974 42 88 THE CZECH REPUBLIC ESAB VAMBERK s.r.o. Vamberk Tel: +420 2 819 40 885 Fax: +420 2 819 40 120 DENMARK Aktieselskabet ESAB Herlev Tel: +45 36 30 01 11 Fax: +45 36 30 40 03 FINLAND ESAB Oy Helsinki Tel: +358 9 547 761 Fax: +358 9 547 77 71 FRANCE ESAB France S.A. Cergy Pontoise Tel: +33 1 30 75 55 00 Fax: +33 1 30 75 55 24 GERMANY ESAB GmbH Solingen Tel: +49 212 298 0 Fax: +49 212 298 218 GREAT BRITAIN ESAB Group (UK) Ltd Waltham Cross Tel: +44 1992 76 85 15 Fax: +44 1992 71 58 03 ESAB Automation Ltd Andover Tel: +44 1264 33 22 33 Fax: +44 1264 33 20 74 HUNGARY ESAB Kft Budapest Tel: +36 1 20 44 182 Fax: +36 1 20 44 186 ITALY ESAB Saldatura S.p.A. Bareggio (Mi) Tel: +39 02 97 96 8.1 Fax: +39 02 97 96 87 01 THE NETHERLANDS ESAB Nederland B.V. Amersfoort Tel: +31 33 422 35 55 Fax: +31 33 422 35 44	NORWAY AS ESAB Larvik Tel: +47 33 12 10 00 Fax: +47 33 11 52 03 POLAND ESAB Sp.zo.o. Katowice Tel: +48 32 351 11 00 Fax: +48 32 351 11 20 PORTUGAL ESAB Lda Lisbon Tel: +351 8 310 960 Fax: +351 1 859 1277 ROMANIA ESAB Romania Trading SRL Bucharest Tel: +40 316 900 600 Fax: +40 316 900 601 RUSSIA LLC ESAB Moscow Tel: +7 (495) 663 20 08 Fax: +7 (495) 663 20 09 SLOVAKIA ESAB Slovakia s.r.o. Bratislava Tel: +421 7 44 88 24 26 Fax: +421 7 44 88 87 41 SPAIN ESAB Ibérica S.A. Alcalá de Henares (MADRID) Tel: +34 91 878 3600 Fax: +34 91 802 3461 SWEDEN ESAB Sverige AB Gothenburg Tel: +46 31 50 95 00 Fax: +46 31 50 92 22 ESAB international AB Gothenburg Tel: +46 31 50 90 00 Fax: +46 31 50 93 60 SWITZERLAND ESAB AG Dietikon Tel: +41 1 741 25 25 Fax: +41 1 740 30 55 UKRAINE ESAB Ukraine LLC Kiev Tel: +38 (044) 501 23 24 Fax: +38 (044) 575 21 88	North and South America ARGENTINA CONARCO Buenos Aires Tel: +54 11 4 753 4039 Fax: +54 11 4 753 6313 BRAZIL ESAB S.A. Contagem-MG Tel: +55 31 2191 4333 Fax: +55 31 2191 4440 CANADA ESAB Group Canada Inc. Mississauga, Ontario Tel: +1 905 670 02 20 Fax: +1 905 670 48 79 MEXICO ESAB Mexico S.A. Monterrey Tel: +52 8 350 5959 Fax: +52 8 350 7554 USA ESAB Welding & Cutting Products Florence, SC Tel: +1 843 669 44 11 Fax: +1 843 664 57 48 Asia/Pacific CHINA Shanghai ESAB A/P Shanghai Tel: +86 21 2326 3000 Fax: +86 21 6566 6622 INDIA ESAB India Ltd Calcutta Tel: +91 33 478 45 17 Fax: +91 33 468 18 80 INDONESIA P.T. ESABindo Pratama Jakarta Tel: +62 21 460 0188 Fax: +62 21 461 2929 JAPAN ESAB Japan Tokyo Tel: +81 45 670 7073 Fax: +81 45 670 7001 MALAYSIA ESAB (Malaysia) Snd Bhd USJ Tel: +603 8023 7835 Fax: +603 8023 0225 SINGAPORE ESAB Asia/Pacific Pte Ltd Singapore Tel: +65 6861 43 22 Fax: +65 6861 31 95	SOUTH KOREA ESAB SeAH Corporation Kyungnam Tel: +82 55 269 8170 Fax: +82 55 289 8864 UNITED ARAB EMIRATES ESAB Middle East FZE Dubai Tel: +971 4 887 21 11 Fax: +971 4 887 22 63 Africa EGYPT ESAB Egypt Dokki-Cairo Tel: +20 2 390 96 69 Fax: +20 2 393 32 13 SOUTH AFRICA ESAB Africa Welding & Cutting Ltd Durbanvill 7570 - Cape Town Tel: +27 (0)21 975 8924 Distributors <i>For addresses and phone numbers to our distributors in other countries, please visit our home page</i> www.esab.com
---	--	--	---



ESAB AB
SE-695 81 LAXÅ
SWEDEN
Phone +46 584 81 000

www.esab.com

